

How to use eSIM?

IOS Samsung Galaxy Google Pixel



::! ? 68

A stable internet connection

is a must be	efore inst	alling eSIM.	
	Q Search		

			31
	Settings	•••••	
⊬	Airplane Mode	0	
?	Wi-Fi	weitaige_5G	>
*	Bluetooth	On	>
(կ»	Cellular / Mobile Data	a	>
	Notifications		>
((ا	Sounds & Haptics		>
C	Focus		>
I	Screen Time		>
\bigcirc	General		>
	Control Center		>
AA	Display & Brightness		>
=	Home Screen		>
Ť	Accessibility		>
	Wallpaper		>
	Siri & Search		>
A			





.... 🗢 75


((†))

Set Up Cellular

You can transfer a phone number from a nearby iPhone, or scan a QR code provided by your carrier.

Learn More...





Scan QR code

Position the QR code from your carrier in the frame.

Learn More...

((†))

Activate eSIM

An eSIM from Drei is ready to be activated on this iPhone.

Continue

Enter Details Manually

::!! ? 30

::!! ? 30

Back

>

((†))

Cellular Setup Complete

Your Drei eSIM is now active on this iPhone.

Cellular Plan Labels

Choose labels for each of your cellular plans.

Primary

LABEL FOR YOUR Drei PLAN



Default Line

:.... 穼 30

Your default line is used to call or send messages to people who are not in your contacts.

The people in your contacts can be assigned a preferred line at any time in the Contacts app.


Primary	✓

Business

You can customize this later in Settings.



OS 	till ? Eack	
iMessage & FaceTime	Cellular Data Choose your default line for cellular data. If you want the best coverage, you can enable cellular data fallback.	
Choose which cellular plans you want to use with iMessage and FaceTime for your Apple ID.	PrimaryBusiness 	
 Primary +86 Business Your new 1010 / csl plan 	Allow Cellular Data Switching	Why is the Allow Cellular Data Switching set to OFF?
	Turning this feature on will allow your phone to use cellular data from both lines depending on coverage and availability. You can change your selection later in Settings > Cellular > Cellular Data.	Allow Cellular Data Switching must be set to OFF so that could avoid using the network of the Primary SIM and incurring additional dat charges.
Continue	Done	



How do I check the call /text message from my home country?

Please set the Default Voice Line to Primary, and you could check the call or text message from your country. However, there may be charges for receiving and sending letters.So please do! Use the data phone (Facebook,Line etc.)to contact your friends!

eSIM Settings is completed!!!

If you have followed all the above steps but still not successfully connected to the network, then check the **APN Settings**.

N	D	: 🗢 👀
	ilular 1010 / cs	sl
	Cellular Plan Label	Business >
	Turn On This Line	
	1010 / CSL	
	Network Selection	>
	My Number	
	Wi-Fi Calling	Off >
	Voice & Data	4G >
	Cellular Data Network	>
	Data Roaming	
	Carrier Services	>
	SIM PIN	>
	SIM Applications	>
	Low Data Mode	
	Low Data Mode helps reduce cel When Low Data Mode is turned o and background tasks, such as F paused.	on, automatic updates

Limit IP Address Tracking

APN Settings * Each eSIM has a different APN, please check the product detail page for specific APN settings.

ngs Cellular	: २
Cellular Data	Business >
Set Up Personal Hotspot	
Turn off cellular data to restrict a including email, web browsing, ar	
Default Voice Line	Primary >
SIMs	
Primary +86	On >
Business	On >
Add eSIM	
CELLULAR DATA FOR BUSINESS	
Current Period	0 bytes
Current Period Roaming	0 bytes
5	
App Store	

BC eSIM

Calendar

~

in Sell	ings. 🧃	
ılular	中華電信	::!! ? (
Cellular Plan La	abel	Business >
Turn On This L	ine	
中華電信 My Number		
Wi-Fi Calling		Off >
√oice & Data		4G >
Cellular Data N	etwork	>
Data Roaming		
Carrier Service	S	>
SIM PIN		>
SIM Applicatio	าร	>
Low Data Mode	e Ips reduce cellular	data usage.
When Low Data Mo	ode is turned on, au sks, such as Photo	utomatic updates
Limit IP Addres	s Tracking	

Limit IP address tracking by hiding your IP address

from known trackers in Mail and Safari.


* Images for reference only.

		::!! † E
華電信	Cellular Data	
CELLULAR DATA		
APN		
Username		
Password		
MMS		
APN		
Username		
Password		
MMSC		
MMS Proxy		
MMS Max Me	ssage Size	
MMS UA Prof	URL	
PERSONAL HOTS	POT	
APN		
Username		
Password		

a 🖪 🖸	⊠ ¥ ≅ रू• ⊗ 100% ∎	2	1 °o, ⊠ °o, 🚳 🖏	第一会・〇 100%	3) 19 (a)	¥ ≅• © 100%
Settings	Q		< Connections	Q			SIM manager	
Samsung a			Wi-Fi weitaige_a1_5G			SIM ca		
	ections		Bluetooth			1	SIM 1 3HK Unknown number	
	Bluetooth • SIM manager		NFC and contactless payments	s		2	No SIM card	
	ed devices • Samsung DeX • Android Auto		Airplane mode					
	化复制物物物等等的物物物物物物物物物物物		All plate mode			eSIMs		
Modes ar Modes • Ro	nd Routines	SIN	Amanager		1	eSIMs	eSIM 4 SoftBank 00000000	
Modes • Ro Sounds a		SIN]		eSIM 4 SoftBank 00000000 eSIM 7 中華電信_Chunghwa Telecom	
Notificati	nd vibration • • Ringtone	SIN	/I manager]	2	eSIM 4 SoftBank 00000000 eSIM 7 中華電信_Chunghwa Telecom Unknown number	
Modes + Ro Sounds a Sound mode Notificati Status bar • Display Brightness	outines ond vibration e • Ringtone ons	SIN	/ manager Data usage			22 22 22 Ad	eSIM 4 SoftBank 00000000 eSIM 7 中華電信_Chunghwa Telecom Unknown number eSIM 3 中華電信_Chunghwa Telecom Unknown number	
 Modes • Ro Sounds a Sound mode Notificati Status bar • Display Brightness bar Wallpape 	outines and vibration e • Ringtone ons • Do not disturb	SIN	A manager Data usage Mobile Hotspot and Tethering		+	2 2 2 2 2 2 0 0 0 0 0 0 0	eSIM 4 SoftBank 00000000 eSIM 7 中華電信_Chunghwa Telecom Unknown number eSIM 3 中華電信_Chunghwa Telecom Unknown pumber	can connect

	Soon the OD and a your get from your	
Choose how to add your eSIM	Scan the QR code you got from your service provider. Billion Connect	Contemposities the second state of the second
Scan QR code		
	Enter activation code	Add

E	ج. 🖪 (ج. ۵ 🕷 🖘 🛇 99% 🗈	8 C 🗷 🖻 🖂 🔹 🕸 🕷 99% 🗈	99%∎
	SIM cards	< eSIM 5 On	< eSIM 5 On
	 SIM 1 3HK Unknown number No SIM card 	Name	Icon Enter SIM name
2	eSIM 5 中華電信_Chunghwa Telecom Unknown number	More information Remove	BC Cancel Done
	eSIM 4 SoftBank 00000000		K BC BE BUT 1 2 3 4 5 6 7 8 9 0
	eSIM 7 中華電信_Chunghwa Telecom Unknown number eSIM 3		qwertyuiop asdfghjkl
	 Add eSIM Download an eSIM so you can connect to mobile networks without a physical SIM card. 		<pre></pre>



eSIM Settings is completed!!!

If you have followed all the above steps but still not successfully connected to the network, then check the **APN Settings**.

Why is the Data switching set to OFF?

Data conversion must be set to OFF in order **not to use baseline SIM** (basic carrier) data and **not incur costs for data usage**.

Settings	 Images for reference only. Each eSIM has a different APN, please check the product deta specific APN settings.
C ■ © © © © N ⊕ 199% ■	
< Connections Q	< Access Point Names Add : < Edit access point :
Wi-Fi weitaige_a1_5G	BC Name
Wi-Fi Calling	CHT Internet
Bluetooth	CHTIMS
NFC and contactless payments	CHT MMS Port
Airplane mode	emome Not set
Mobile networks	Password
Data usage	Not set
Mobile Hotspot and Tethering	MMSC Not set
More connection settings	Multimedia message proxy Not set
	Multimedia message port

Google Pixel



E	3		\$ ♥⊿ ∎				
	Network & internet						
	•	Internet weitaige_5G					
	۲	Calls & SMS China Unicom					
		SIMs China Unicom	+				
	¥	Airplane mode					
	0	Hotspot & tethering Off					
	0	Data Saver Off					
	ଫ	VPN None					
	Priv _{Autor}	rate DNS matic					

Google Pixel

1

x 🖓 🖌 🗎

Connect to mobile network

To use a new SIM card, you'll need to remove the one that's currently in the device

Download a SIM instead?
 Add a number using eSIM

G


x •1

6

Download your SIM

•

Connect to your mobile network by downloading the info that's usually on a SIM card. This replaces standard SIM cards and is just as safe.




Open source licenses, Privacy policy and Terms of service



x 🕶 🛛 🗎

Scan QR code from network

If your network provider gave you a QR code, scan it now by keeping the code centered in the box



Need help?

Goo	gle Pixel				
		8	x ~ 1	E	¤ • ⊿ 1
	Use BillionConnect number is available for this device.		nload Finished		SIMs SIM China Unicom Active / Default for mobile data, calls, SMS DOWNLOADED SIM BillionConnect 16 Inactive + Add more
	Use a different network	Close	Settings		

Google Pixel		
BillionConnect 16	BillionConnect 16	BillionConnect 16 Calls preference China Unicom (preferred), BillionConnect 16 SMS preference
Use SIM Erase SIM	Use SIM	China Unicom (preferred), BillionConnect 16 Mobile data Access data using mobile network
Turn on BillionConnect 16? Cancel Yes	Select a SIM for data 1 China Unicom B +861 2 BillionConnect 16	Connect to data services when roaming App data usage Data warning & limit
	Calls preference China Unicom (preferred), BillionConnect 16 SMS preference	Preferred network type ^{5G (recommended)} Carrier settings version
	China Unicom (preferred), BillionConnect 16 Mobile data Access data using mobile network	23458-3300000012.2 2022-06-29 Network
	Roaming Connect to data services when roaming	Automatically select network

